



TV User Guide



wildanet.com | 0800 0699906



What's in the box?

In the box you should find:

- Wildanet TV box
- Remote
- 2x AAA batteries
- HDMI Cable
- Power cable



wildanet **TV**

Getting Connected




Plug in

1. Connect your set top box to your TV via the **HDMI cable** provided
2. Plug the power supply provided into the **DC5V port on your set top box**
3. Plug the power supply into your plug socket
4. Select the correct **HDMI source** on your TV



Pair your remote

5. Follow the on screen instructions for pairing your new remote control
6. Follow the on-screen instructions for connecting your set top box to the internet



Apps & Content

Accessing your content and configuring your apps

The remote control has 6 branded shortcut buttons for the most popular apps: Youtube, Netflix, Prime Video, Disney+ and Freely.

“Guide” button


Access the Freely Live TV guide.

Voice control button

Opens apps or accesses content – press and hold it whilst saying something like “Tom Cruise Movies” or “BBC iPlayer”.

“TiVo” button

Takes you to the Home screen, where you can access apps, recommendations, live TV, and free content.




No aerial. No hassle.

TV made simple with wildanet **TV**

If you're watching live TV, catching up on last night's drama or jumping into Netflix, find everything you need in one place.

Powered by TiVo and Freely, Wildanet TV combines live TV, streaming apps and catch-up.





wildanet.com | 0800 0699906

Certified



Corporation

Wildanet Limited 2026. Westbourne House, West Street, Liskeard, Cornwall, PL14 6BT. Registered in England and Wales no 10586466.